

FINISH: DIRTY GREEN LUSTERSTONE



PRODUCTS: Setcoat Sage or Sherwin Williams "Sawdust", Sage Lusterstone, Green Onyx Lusterstone, Van Dyke Brown Stain and Seal, FX Thinner

TOOLS: Venetian trowel or Japanese trowel, Deco sponge roller, "distender tool" from Adicolor's Desrie product or a piece of styrene or stupid tool or japan scraper or trowel, car washing sponge

BASECOAT: Setcoat Sage or Sherwin Williams "Sawdust" in eggshell.

1. Do a tight skim trowel of Sage Lusterstone over the walls. Let dry.
2. Use a deco sponge roller to roll Green Onyx lusterstone on the walls and pull it down with a "distender tool" from Adicolor's Desire product (you could use polystyrene, a "stupid tool" I think they are called, a trowel or a japan scraper. I just like that distender tool and have them on hand always at job sites).
3. After drying, backfill tightly with Sage Lusterstone on 100% of the wall.
4. Stencil any design you want using Metallic Bronze Palette Deco. Be sure to use stencil adhesive and keep Qtips handy in case of any bleeding. Let dry.
5. The next day, mix Van Dyke Stain and Seal with a lot of FX Thinner and rub it on the walls in a circular motion with a car washing sponge. This is how I "dirty up" the green color.